

Digital Guide / Set Top Box Instructions

As part of our on-going commitment to improve service offerings to all customers we will be performing a software upgrade to many of the video set top boxes within our service areas. Some customers in the following communities may experience a factory default to their set top boxes after this upgrade.

- • Floyd
- • Greene
- • Nora Springs
- • Rockford
- • Rudd
- • Stacyville

If your set top box currently displays the **local time** on the LCD display, the upgrade may cause this to display the current channel you are watching. In addition, some customers may find the auto-tune functions of their remote control have defaulted back to the factory settings as well.

The instructions to reprogram these features are as follows:

Set Display Clock

1. Press **Menu** button on the remote twice
2. Navigate to **Setup** and press **OK**
3. Navigate to **Cable Box Setup**, press **OK**
4. The Front LED Display field will show the default of "Current Channel"
5. Press the **right arrow button** until "Current Time" is displayed on the tab
6. Press **Exit**

Enable Auto-Tune Feature

1. Press **Menu** button on the remote twice
2. Navigate to **Setup** and press **OK**
3. Navigate to **Guide Setup**, press **OK**
4. Navigate to **Channel Entry Behavior** field
5. The Channel Entry Behavior field will show the default of "No-Auto-Tune"
6. Using the arrow keys, select "Auto-Tune"
7. Press **Exit**

If you have any questions or need further assistance please feel free to visit our website at www.omnitel.biz for detailed instructions or call our offices at 641-749-2531